Important Information: System Configuration Card

This server is fitted with a system configuration card. If the card moves during transit then the server will not be able to read the card, and as a result will not install or boot correctly.

If the system configuration card has moved during transit, follow the steps below to make sure it is seated in the server correctly.

Note – The presence of the tie-wrap does not necessarily mean that the card is correctly located in the reader, it is to prevent accidental *removal* of the card only.

Sun Fire™ V120 and Netra™ 120, Netra T1 AC200 and DC200 Servers

The system configuration card is located behind the front bezel. To make sure it is correctly inserted:

1. **Remove the front bezel by pushing on the clips at both ends until they release.**

2. **Press the system configuration card in as far as it will go.**

3. **Replace the bezel and continue installation as documented in the User's Guide that ships with your system.**

Sun Fire™ V100 and Netra™ X1 Servers

The system configuration card is located on the back panel.

1. **Press the system configuration card in as far as it will go.**

2. **Continue installation as documented in the User's Guide that ships with your system.**